


shoulder in a small sling. Slip the point of the bandage under the sling and turn it back and pin it to the bandage on the shoulder. If the shoulder is unable to bear the weight of the arm in a sling, fold a second narrow bandage, place it over the point of the shoulder bandage, carry one end across the chest and the other across the back, and tie in front of the armpit on the opposite side.

BANDAGING THE RIBS

Take two or three four-inch bandages, placed one on top of the other, and bind the chest with them, securely keeping the center of the bandages on the point of the injury. Knot the ends at the opposite side.



BANDAGING THE WRIST

Apply the bandage on the back of the injured wrist. Carry the end of a four-inch bandage around the wrist until the pad is firmly fixed, then cross the ends. Bring the ends forward and fasten with adhesive. A broad sling should be used to support the arm.

BANDAGING FOR ELBOW AND FOREARM

Apply the bandage in that in spiral fashion, making the wire and fastened on the upper arm with a safety pin.

BANDAGING THE ELBOW

The joint must be bent in order to allow a certain amount of movement. Use the figure-of-eight method until the joint is completely covered. Tie in front or, better still, fasten with adhesive tape. Use a narrow sling for support.

Eric Rhein, *Safety Pin*, 1997
 wire, paper, 9 x 6 inches
 Rhein, Eric.006